


# Flexible cover universal DLP trunking 50 x 150 and 50 x 170 - 65 mm cover

White  
length: 2 m

## Cat.Nos for 50 x 150 trunking




## Cat.Nos for 50 x 170 trunking




Selection chart **p. 820-821**  
Wiring capacity chart **see e-catalogue**

Pack	Cat.Nos	Flexible cover universal trunking 50 x 150
12'	0 104 27	<b>Trunking with partition</b> Supplied with: - one 50 x 150 mm body - two flexible 65 mm width covers Fits onto the whole trunking including internal and external angles Installation: can be used with Mosaic/Arteor ranges or DIN rail equipment Length 2 m
24'	0 105 82	<b>Partition</b> Separation partition Length 2 m
20	0 106 91	<b>Joints</b> Body joint For aligning bases during installation
20	0 106 92	Body joint, attached with adhesive (fit at the end of installation)
10	0 108 01	Cover joint for 65 mm cover



Pack	Cat.Nos	Flexible cover universal trunking 50 x 170
4'	0 104 67	<b>Trunking with partition</b> Supplied with: - one 50 x 170 mm body - one flexible 65 mm width cover and two flexible 40 mm width covers Fits onto the whole trunking including internal and external angles Installation: can be used with Mosaic/Arteor ranges or DIN rail equipment Length 2 m
24'	0 105 82	<b>Partition</b> Separation partition Length 2 m
20	0 106 91	<b>Joints</b> Body joint For aligning bases during installation
20	0 106 92	Body joint, attached with adhesive (fit at the end of installation)
10	0 108 01	Cover joint for 65 mm cover
10	0 108 00	Cover joint for 40 mm cover



Pack	Cat.Nos	Angles for flexible cover universal trunking 50 x 150
5	0 106 06	<b>Internal and external bends</b> Include the 3 components making the angle (parts for the top and bottom and the partition junction) on which the flexible cover is fitted Changeable internal bend, from 85° to 95° for 50 x 150 and 50 x 195 mm trunkings
5	0 106 35	Changeable external bend, from 60° to 120° for 50 x 150 and 50 x 195 mm trunkings
5	0 107 89	<b>Flat angle</b> 90° flat angle
10	0 107 03	<b>End cap for flexible cover universal trunking 50 x 100</b> Left or right end cap

Pack	Cat.Nos	Angles for flexible cover universal trunking 50 x 170
5	0 106 50	<b>Internal and external bends</b> Include the 4 components making the angle (parts for the top and bottom and the 2 partition junctions) on which the flexible cover is fitted Changeable internal bend, from 85° to 95° for 50 x 170 and 50 x 195 mm trunkings
5	0 106 38	Changeable external bend, from 60° to 120° for 50 x 170 and 50 x 195 mm trunkings
2	0 107 98	<b>Flat angle</b> 90° flat angle
5	0 107 10	<b>End cap for flexible cover universal trunking 50 x 170</b> Left or right end cap